SAFETY INFORMATION

Your wireless hand-held portable transceiver contains a low-power transmitter. When its push-to-talk button is pressed, the transceiver sends out radio frequency (RF) signals. The device is authorized to operate at a duty factor not to exceed 50%.

In August 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless devices.

Cautions:

 To maintain compliance with the FCC's RF exposure guidelines, hold the transmitter and antenna at least 2 inches (5 centimeters) from your face and speak in a normal voice, with the

© 2000 RadioShack Corporation. All Rights Reserved. RadioShack and RadioShack.com are trademarks used by RadioShack Corporation. antenna pointed up and away from the face. If you wear the handset on your body while using the headset accessory, use only the supplied belt clip for this product and take the handset out of the belt clip while transmitting to ensure that the antenna is at least 1 inch (2.5 centimeters) from your body.

 Use only the supplied antenna. Unauthorized antennas, modifications, or attachments could damage the transmitter and may violate FCC regulations.

RadioShack Corporation Fort Worth, Texas 76102 19-1207 12A00 Printed in China